



MARCH 2012 PRODUCT DATA SHEET

ARDEX RAPIDLAY MEMBRANE

PVC Damp Proofing and Isolating Membrane

Features

- Quick and easy solution when applying floorcoverings over a damp floor
- Provides a stable, moisture resistant barrier substrate
- Perfect for use over damp and contaminated sub-floors
- Reduces or eliminates the need for mechanical preparation
- Ideal for use with ARDEX Flooring Adhesives



Fax: +44 (0)1440 716640

Technical Services Fax: +44 (0)1440 716663 Email: technical.services@ardex.co.uk

ARDEX online: www.ardex.co.uk

ARDEX RAPIDLAY MEMBRANE

PVC Damp Proofing and Isolating Membrane

DESCRIPTION

ARDEX RAPIDLAY MEMBRANE is a specially coated and patterned fibreglass-reinforced sheet underlay designed to overcome the problems sometimes encountered in laying floorcoverings, particularly sheet vinyl flooring, over new or old sub-floors in domestic and light commercial areas.

ARDEX RAPIDLAY MEMBRANE can be laid over a variety of surfaces, such as old sub-floors, vinyl flooring, ceramic tiling, sheet metal, sub-floors contaminated with oil or paint, or damp sub-floors. It can also be used over asphalt sub-floors.

The main advantages of ARDEX RAPIDLAY MEMBRANE are:

- It provides a continuous base which is stable and resistant to damp
- It cuts down laying time as there is no need to wait for the normal subfloor drying times
- · It is dimensionally stable
- Quick installation can be achieved as it is a sheet system
- Allows for a new temporary floor to be laid over an existing floor (without potential adhesive damage on uplifting)
- · Low VOC and solvent free product

USE

- Screed or concrete substrates where construction moisture has not fully dried out (max. 5% moisture content, 92% RH)
- Anhydrite Screeds with a maximum of 2% moisture content (carbide method)
- Areas where sub-floors have been exposed to water spillage
- Old sub-floors which do not contain a fully functioning damp proof membrane
- Over old, soundly fixed flooring when a temporary covering is to be applied (without adhesive)
- Suitable for use on heated concrete or cement/sand screeds up to 27°C maximum temperature.

ARDEX RAPIDLAY MEMBRANE should NOT be used in:

- Areas that are subjected to heavy wheeled traffic such as forklift or pallet trucks, chair castors, etc.
- On timber bases that are not adequately ventilated
- On sub-floors that are subject to hydrostatic pressure

- On sub-floors which contain an effective damp proof membrane, but exceed a relative humidity of 97% and on sub-floors with no damp proof membrane and a relative humidity above 92%
- On magnesite or composite floors
 Biologically sensitive areas, or where
 floorings must be fully adhered, such
 as prisons

APPLICATION

The sub-floor should be sufficiently smooth and flat. If not, then, consult the ARDITEX NA low odour, latex levelling and smoothing compound data sheet for information on smoothing and levelling the sub-floor. For example, joints in ceramic tiling may need to be pre-smoothed if they are wide and/or recessed, to prevent reflection of the joints through the flooring.

ARDEX RAPIDLAY MEMBRANE should be laid, without using an adhesive, with the patterned, textured surface on the underside, and cut along walls and upstands leaving a 3-6mm gap. The joints should be abutted and fixed on the back (i.e. from above) using ARDEX RAPIDLAY MEMBRANE Jointing Tape or other 50mm wide adhesive tape (suitable for damp conditions where necessary). The underlay must lay flat.

ARDEX RAPIDLAY MEMBRANE should be laid in the same direction as the final flooring. The positions of the joints in the flooring should not correspond and be at least 30cm away from the joints in the ARDEX RAPIDLAY MEMBRANE. Apply under conditions appropriate for the application of the final floor covering. **NOTE:** Use gloves when handling.

The ARDEX RAPIDLAY MEMBRANE must be allowed to acclimatise for at least 24 hours at a minimum temperature of 18°C prior to use. Ideally the ARDEX RAPIDLAY MEMBRANE and floorcovering should be rolled out and allowed to acclimatise and lay flat prior to fixing.

Either form close butt joints or overlap the adjacent sheets and cut through to form a close fitting butt joint. Do not compress the joint otherwise a ridge will form under the floor covering.

The flooring should be adhered to the ARDEX RAPIDLAY MEMBRANE with a suitable adhesive. Recommended ARDEX adhesives include ARDEX AF 100 pressure sensitive flooring adhesive or ARDEX AF 2510 PU flooring adhesive.

Use ARDEX AF 2510 PU flooring adhesive where moisture in the sub-floor exceeds 92%.

It is important to apply the adhesive with an appropriate notched trowel/roller. Allow 24 hours before welding seams in the flooring.

When installing ARDEX RAPIDLAY MEMBRANE (particularly in areas where moisture spillage can occur) and in wet areas, the complete system should be sealed using conventional clamp type drain gulleys, including sealing of pipes etc. and the perimeter must be sealed/capped/coved as appropriate.

At transition points, the flooring should be secured with a mechanical fixing.

PACKAGING AND COVERAGE

ROLL WIDTH	1.45m
ROLL LENGTH	25m
ROLL COVERAGE	36.25m ²
WEIGHT	58kg
THICKNESS	1.4mm

STORAGE

Store ARDEX RAPIDLAY MEMBRANE in dry warehouse conditions. Take care not to damage the ends of the rolls during transport or storage.

TECHNICAL DATA

Parameters Specification Test Method Weight (kg/m²) 1.6

Dimensional

Stability +/- 0.2% EN 434

Flame Propagation

mm/min max. 100 ISO 3795

NOTE: The information supplied in our literature or given by our employees is based upon extensive experience and, together with that supplied by our agents or distributors, is given in good faith in order to help you. Our Company policy is one of continuous Research and Development; we therefore reserve the right to update this information at any time without prior notice. We also guarantee the consistent high quality of our products; however, as we have no control over site conditions or the execution of the work, we accept no liability for any loss or damage which may arise as a

Country specific recommendations, depending on local standards, codes of practice, building regulations or industry guidelines, may affect specific installation recommendations.

TECHNICAL ADVICE HELPLINE 01440 714939

ARDEX online www.ardex.co.uk